

Model BMR 1000 **HOT AIR SEALER**



**VALUE, VERSATILITY
AND RELIABILITY**

S S&S SERVICE PARTS, INC.
S PACKAGING MACHINERY & SYSTEMS

715-246-3299

www.BagCloser.com

The model BMR 1000 Hot Air Sealer is a heavy duty bag closing machine equipped with many unique features. Designed specifically for minimum maintenance with maximum reliability, which is essential for long continuous production runs. Combined with our unmatched customer service the BMR 1000 is the only choice in hot air sealers today.

The BMR 1000 Hot Air Sealer offers the following features:

- Designed for Automatic or Manual Lines
- Solid State Temperature Controls
- U.S. Approved Control Panel
- Cooling Section to Solidify Bag Seal
- Compression Belts for Gripping Bag Top
- Stainless Steel Guarding
- Allen Bradley Controls
- Adjustable Speed Control (D.C. Variable Speed)
- Right to Left Feed Direction

SPECIFICATIONS

Sealing Speed: 0-800 Per Minute
Heat Manifolds: 2 pcs. 11" Long
Heat Control: Watlow Digital
SD31 Digital
Motor: Leeson 1/3 HP
Power Source: 220
Volt 1 Phase
Maximum Current: 15 Amps
Pneumatic Air Source at
25 PSI at 7 CFM

OPTIONS

- Casters
- Bag Top Trimmers
- Continuous Coder
- Double Seal
- Extra Heat
- In-Line Conveyor
- Bag Top Cleaner
- Complete Stainless Steel Construction
- Complete Systems Available for Manual or Completely Automatic Lines

S&S Service Parts, Inc.
409 St. Croix Avenue
New Richmond, WI 54017
715-246-3299

Represented by: